



Dock Bumper Installation Instructions

What you'll need

- cordless drill
- socket adapter
- bumper

Note: if you don't have a socket adapter, all you need is a drill and a socket wrench. In this case, place the bumper temporarily in the desired position and mark the holes with the drill, a pencil, or even a screwdriver. Remove the bumper and pre-drill the holes. Then attach the bumper.

Side bumper installation

1. place the bumper on the side of the dock at the desired height with the holes pointing up
2. attach first bolt through center hole (so level can be adjusted)
3. secure the bumper with the remaining bolts

Corner bumper installation

Flat installation

1. insert the first bolt at the desired height (holes pointing up)
2. level the bumper and attach the second bolt

Corner installation

1. before attaching, bend it around the corner to find the best position
2. find the desired height on one side and attach the first bolt
3. find the same height on the other side and attach the second bolt